

# Using a Finger Scanner Correctly

- ① **Lock** – Position your finger where the first knuckle joint meets the Placement Guide.
- ② **Drop** – Lower the pad of your fingertip evenly onto the center of the finger scanner. Use moderate pressure.
- ③ **Hold** – Keep your finger on the sensor until the terminal accepts the finger scan. Do not move or roll your finger.

